

1. SLIP THE CENTER CHANNEL END FEED BRACKET TABS INTO THE TRACK END, AND MAKE SURE THE BRACKET IS PUSHED DIRECTLY AGAINST THE RACEWAY BASE END.
2. INSTALL SUPPLIED SCREWS INTO THE BRACKET TAB TAPS, AND TIGHTEN THEM TO SECURELY CAPTURE BRACKET.
3. ROUTE WIRES/CABLES THRU OPENING AND MAKE ELECTRICAL CONNECTIONS AS REQUIRED.

