

1. INSTALL BOX CHASSIS ONTO RACEWAY BASE. END KIT & RACEWAY BASE EDGE MUST BE INSTALLED FIRST.
2. FULLY INSERT 16" LONG PLASTIC BARRIER EXTENSION STRIP (PROVIDED BY FSR) IN BASE OF HUBBELL SERVICE POLE (PROVIDED BY CUSTOMER) UNTIL IT CONTACTS THE EXISTING BARRIER, LEAVING NO GAP GREATER THAN 1/16" BETWEEN THE POWER AND DATA CHANNELS. ENSURE THAT THE BARRIER EXTENSION STRIP IS CORRECTLY INSTALLED IN THE SAME SLOT AND ORIENTATION AS THE EXISTING BARRIER.
3. PLACE POWER POLE PLATE ON TOP OF BOX CHASSIS THEN INSERT HUBBELL POWER POLE (HBLPP-) INTO THE PLATE. DO NOT INSTALL ANY SCREWS AT THIS TIME. IN ORDER TO MAINTAIN SEPARATION OF CIRCUITS, POWER POLE INTERNAL CHANNEL DIVIDER MUST ALIGN WITH DIVIDER SUPPORT.
4. SLIDE POWER POLE PLATE UP OUT OF THE WAY TO MAKE WIRING CONNECTIONS AS REQUIRED.
5. SLIDE POWER POLE PLATE DOWN AND INSTALL MOUNTING AND SET SCREWS.
6. INSTALL END CAPS USING SUPPLIED SCREWS.

