

FSR SW-TPE-CS Wall Edging Installation Instructions

244 Bergen Boulevard, Woodland Park, NJ 07424, Phone: 973.785.4347 - FAX 973.785.4207

HOW TO INSTALL THE SMART-WAY EDGING VIDEO:
<https://vimeo.com/656380210>

1. INSTALL RACEWAY BASE (SOLD SEPARATELY) PER INSTALLATION INSTRUCTIONS.
2. INSTALL SW-TPE-CS WALL EDGING ONTO RACEWAY BASE AS SHOWN.
3. ROUTE WIRING THRU RACEWAY BASE AS REQUIRED AND INSTALL RACEWAY COVER ONTO RACEWAY BASE.



Scan To See How To Install The Smart-Way Edging:

