

FSR SWT72-MLS-ALU / SWT72-MLS-SLT Installation Instructions

244 Bergen Boulevard, Woodland Park, NJ 07424, Phone: 973.785.4347 - FAX 973.785.4207

1. SELECT AND PROVIDE THE APPROPRIATE #8 OR LARGER HARDWARE, FOR THE SURFACE THAT THE RACEWAY IS BEING MOUNTED TO.
2. DRILL A PILOT HOLE THROUGH THE CENTER OF THE COVER AND BASE, IN THE 3 LOCATIONS DEFINED BELOW.
3. USING A 3/8" DRILL BIT, OPEN UP THE PILOT HOLE IN THE COVER OF THE RACEWAY ONLY.
4. INSTALL THE MOUNTING HARDWARE, IN THE PREVIOUSLY DRILLED HOLES, SECURING RACEWAY TO THE MOUNTED SURFACE IN THE 3 LOCATIONS DEFINED BELOW.
5. INSTALL THE 3/8" HOLE PLUGS INTO THE COVER OPENINGS, AFTER THE HARDWARE HAS BEEN INSTALLED.

