

NOTICE: For installation by a qualified electrician in accordance with all national and local electrical codes and communications standards. Adhere to the following instructions and any instructions included with the individual raceway components.

1. Install box chassis to raceway base. End kit & raceway base edge must be installed first if mounting box on raceway end.
2. Route wires and cables and install high voltage block off plates as required.
3. Install cover with supplied screw.

Classification; CTS/DTS 3.102 Flushfloor, 3.103 Onfloor, 6.101.1 Dry-Treatment Only, 6.2.6 10J Impact
6.102.3 1,000 N Small Surface Load, 6.4.1 Non-Flame Propagating
IP41; Min Storage Temp - 25°C; Installation and Application Temp - 15°C to 60°C

CAUTION: Ensure Edge Of Raceway Cover Is Deburred.

WARNING: Use Low Voltage Devices Only In Low Voltage Compartments

WARNING: Use High Voltage Devices Only In High Voltage Compartments

