



INSTALLATION SEQUENCE:

- 1) INSTALL FSR #17519, STANDOFFS WITH WASHERS INTO PLACE ON THE SMARTFIT 8" BASE MOUNTING PLATE (4 PLACES).
- 2) INSTALL THE WALL PLATE UNIT ONTO THE STANDOFFS WITH THE MANUFACTURER-PROVIDED MOUNTING SCREWS.
- 3) INSTALL THE HUBBELL COVER PLATE TO THE WALL PLATE USING THE HUBBELL-PROVIDED ATTACHMENT SCREWS.