

FSR CB-BRK-1G/2G/6IPS/12IPS ACCESSORY INTERNAL BRACKET INSTALLATION INSTRUCTIONS

244 Bergen Boulevard, Woodland Park, NJ 07424, Phone: 973.785.4347 - Fax: 973.785.4207

1. INSTALLATION AND WIRING OF ELECTRONIC DEVICES ONTO THE ACCESSORY INTERNAL BRACKET MAY BE DONE BEFORE OR AFTER SECURING BRACKET INTO CEILING BOX.
2. SECURE ACCESSORY INTERNAL BRACKET TO CEILING BOX WITH SUPPLIED HARDWARE AS SHOWN. BRACKET LOCATION TO BE DETERMINED BY CUSTOMER/ELECTRICIAN. BRACKET CAN BE MOUNTED USING FACTORY PILOT HOLES OR BY ADDING ADDITIONAL HOLES.
3. SECURE WIRING AS REQUIRED WITH WIRE SADDLES OR CABLE TIES ONTO ACCESSORY INTERNAL BRACKET AS SHOWN.

