





TO CONNECT TO DV-HSW-21 OR DV-MFSW-21  
INSTALL WIRE TAILS FROM T6 BOX AS SHOWN BELOW.  
(JUMPER JP2 & JP3 SHOULD NOT BE INSTALLED)

