
Disassemble lock as shown and reassemble onto new door. NOTE ORIENTATION OF CAM.



43474 LIT1897