


FSR WB-TSC-SM-7 Installation Instructions

244 Bergen Boulevard, Woodland Park, NJ 07424, Phone: 973.785.4347 - Fax: 973.785.4207

Center 2-gang mounting holes in cover with 2-gang mounting holes in Electrical Outlet Box and secure cover to wall with required #6 hardware (by others).



Cover can be installed so that door opens upward or downward.


Touch Panel Installation:

Touch Panel Maximum Size: 8.00"W x 4.70"H x .925"D

Refer and follow the touch panel's installation instructions for mounting on a 2-gang electrical box.

The drawing below depicts one possible touch panel and is for reference only.

Your specific panel may require special brackets that may or may not be supplied with your touch screen. Contact the screen manufacturer for 2-gang mounting brackets and instruction.



Spring Removal for Free Swinging Door:

To remove door springs, remove nuts, spacers and springs as shown on both sides and discard.

