


Reinstall Cover Assembly

Make wiring connections as required and reinstall Cover Assembly back onto box. Tighten screws to secure Cover to Box.



FSR WB-TSC-FM-10 Installation Instructions


244 Bergen Boulevard, Woodland Park, NJ 07424, Phone: 973.785.4347 - Fax: 973.785.4207

Remove Cover Assembly

Loosen 4x Cover screws (do not remove) to remove Cover Assembly from Box.



NOTICE: For installation by qualified personnel in accordance with all national and local electrical codes and communication standards. Adhere to the following instructions and any instructions included with the individual components.

COVER MUST BE MOUNTED PLUMB ON A FLAT SURFACE



Box Installation

Mount to studs as shown.



Touchscreen Installation and Mounting Options:

Touchscreen Maxium Size: See Standard and Extra Depth Touchscreen Sizes Below


Refer and follow the touchscreen's installation instructions for mounting on a 2-gang electrical box.

The drawing below depicts one possible touchscreen and is for reference only.

Your specific screen may require special brackets that may or may not be supplied with your touchscreen. Contact the screen manufacturer for mounting brackets and instruction.

NOTE: Ensure mounting plate is properly positioned so that door can fully close with touchscreen before installing Cover Assembly onto box.

2-Gang Mounting Plate



VESA 75mm x 75mm Mounting Plate

