



NOTICE: For installation by qualified personnel in accordance with all national and local electrical codes and communication standards. Adhere to the following instructions and any instructions included with the individual components.

Outdoor Wall Box Installation:

1. Touchscreen Mounting Plate and Sub-Plate must be removed to mount Wall Box.



2. Mount Wall Box to wall with hardware (by others) as required with supplied Sealing Washers. Route conduit and fittings (by others) as required.




This page intentionally left blank.


Touchscreen Installation and Mounting Options:

Bracket Mounting Options:

Brackets can be mounted in 2 orientations as shown. Brackets have a 5/8" adjustment range. Option B allows Touchscreen Mounting Plate to be mounted closer to door.



Reinstall Sub-Plate.



Touchscreen Installation and Mounting Options:

Touchscreen Maximum Size: 9.25" W x 7.50" H x 2.30" D

Refer and follow the touchscreen's installation instructions for mounting on a 2-gang or Vesa 75 box.

The drawing below depicts one possible touchscreen and is for reference only.

Your specific touchscreen may require special brackets that may or may not be supplied with your touchscreen. Contact the touchscreen manufacturer for mounting brackets and instruction.

