

1. INSTALL THE 4" POKE-THRU (SOLD SEPARATELY) IN ACCORDANCE WITH THE INSTALLATION INSTRUCTIONS, ORIENTING THE POKE-THRU IN IT'S HOLE SO THAT THE UPPER ATTACHMENT ALIGNS THE TRANSITION FITTING IN THE DESIRED RACEWAY DIRECTION ON THE FLOOR.
2. INSTALL SUPPLIED CHASE NIPPLES ONTO 4" POKE-THRU.
3. FASTEN THE CHASSIS ASSEMBLY DOWN TO THE FLOOR WITH MINIMUM OF 2 FLOOR ATTACHMENT SCREWS.
4. INSTALL THE RACEWAY ONTO THE (2) CHASSIS ASSEMBLY TABS, AND SECURE WITH THE (2) SET SCREWS PROVIDED. FURTHER SECURE THE RACEWAY TO THE FLOOR AS NECESSARY.
5. WIRE IN ACCORDANCE WITH NEC AND LOCAL ELECTRICAL CODE, ENSURING HIGH-VOLTAGE AND LOW-VOLTAGE WIRING ARE ALWAYS SEPARATED. NORMALLY, THE RACEWAY BASE CENTER CHANNEL IS THE LOW-VOLTAGE CHANNEL.
6. INSTALL THE RACEWAY COVER, RIGHT AGAINST THE RACEWAY-ENTRANCE WALLS OF THE TRANSITION FITTING CHASSIS ASSEMBLY. TRANSITION FITTING COVER IS DESIGNED TO OVERLAP CUT EDGE OF RACEWAY COVER.
7. INSTALL THE TRANSITION FITTING COVER WITH THE (4) SCREWS PROVIDED.

